



Test Ua1: Signal to Ua1:VIN+, Observ Ua1:Vout1, Ground to Ua2:VIN+, Open Ua2:Vout2
Test Ua2: Signal to Ua2:VIN+, Observ Ua2:Vout2, Ground to Ua2:VIN+, Open Ua1:Vout1