



.tran 0 0.5 0 100n Download opamp(NS),shunt regulator(TI), LED(rohm) model.

Don't trim output voltage loading G.M. tube.
This circuit may generate upto 1.5kV or more, too high voltage can kill some kind of tube.

Draw: FTechWorks. 2011.12.3