



To TTL-232R-5V
38400bps, 8bit, Non Parity, 1stop
Commands:
Single character [0..9, a..f] controls PORTC output.
Single character [r..t] reads analog voltage at AN0 to AN2 in 3 digit hex.
Ignore all other characters those are not command.
Echo back all received characters.

- Change Notes:
 Δ1, Δ2, Δ3, Δ4, Δ12
 To reduce more AC adapter noise.
 Δ5
 E6 serie may be more handy.
 Δ6
 Trimming voltage becomes more easy.
 Δ7
 Ensure keep TND012 on when Cx turns Hi-Z.
 Δ8, Δ9
 Out low/high to turn Off/On PhotoRelay.
 Δ10, Δ11
 Supress surge voltage.
 Δ13
 Assure capacitance after long time passed.
 Δ14
 Supress surge current
 Δ15
 Found in stock
 Δ16
 More small parts.

Title: USB BUS Switcher.
 Draw: FtechWorks.
 Date: 2013.09.18.
 Version: 2.0.